

## TAPE LOADING

**BASIC PROGRAMS:** ("BASIC" on tape label)

Press RESET. Enter BASIC by holding down the CTRL key and pressing B, then release them both and press RETURN. Type LOAD and start the tape recorder and then press RETURN. Wait for the second "BEEP" then type RUN and press RETURN.

**ASSEMBLY LANGUAGE PROGRAMS:**

Press RESET. Type the loading address and "R" as on the tape label (eg. 300.1B00R). Start the tape recorder then press RETURN. Wait for the 1st "BEEP" then hold down the CTRL key and press Y. Then release them both and press RETURN.